



INSTALL | BASILISK

FOR STATIC WHITE & RGBW



INSTALLATION INSTRUCTIONS

1. All installations must adhere to relevant electrical code requirements at the local and national levels
2. A licensed professional should preform installation to meet safety standards and electrical code requirements
3. Use only Class 2 DC constant voltage LED driver to comply with UL safety standards
4. Do not install the product underwater.
5. A dedicated driver connection is required for each maximum run.
6. The Basilisk can't be dismantled separately.
7. Do not cut off the cable wire of connector for customization.



rev 01/26


© 2026 Ace Illuminations. All rights reserved.
Specifications and content subject to change without notice. Protected by international copyright laws.
info@aceilluminations.com | 702.960.4249

cont. on 1



INSTALL | BASILISK




Fixed Bracket Installation Guide




Accessories:
 ① MOUNTING CLIP
 ② ROUND HEAD SCREW
 ③ SCREW
 ④ PLASTIC END CAP
 ⑤ END CAP
 ⑥ LEADER CABLE




1. Use a screwdriver to screw the mounting clip to the bottom of BASILISK, as shown in picture 1.
2. Tighten screw in a clockwise direction, screw off round head screw to loosen in a counterclockwise direction. One at the beginning and the other at the end of the fixture, as shown in picture 2.
3. Mounting clip have been already screwed on tight to the bottom of basilisk, as shown in picture 3.




Picture 4




Picture 5




Picture 6



Picture 7



Picture 8



Picture 9

4. After mounting clip has been installed, bend the product in a semi-circular shape. We need to mark the surface for the screw positions on the ground with a marker, as shown in picture 4.
5. When all the position of screws have been marked on the ground, then use the percision drill to drill the holes on the ground, as show in the picture 5.
6. When all the holes have been drilled, plastic anchor needs to be inserted into the holes, as shown in the picture 6.
7. Screws the product on the ground with a screw driver, as shown in the picture 7.
8. When all the screws have been tighten, the product has been installed and fixed on the ground around the column, as shown in picture 8
9. Push cable connector from the leader cable to connect with the fixture, as shown in picture 9



rev 01/26

© 2026 Ace Illuminations. All rights reserved.








Specifications and content subject to change without notice. Protected by international copyright laws.
 info@ace illuminations.com | 702.960.4249

cont. on 2

INSTALL | BASILISK



Adjustable Bracket Installation Guide



4. After adjustable bracket has been installed, to install the basilisk to the wall, we need to mark the screw position on the wall with a marker, as shown in picture 4.
5. When all the position of screws have been marked on the wall, then use the percussion drill to drill the holes on the wall, as shown in picture 5.
6. When all the holes have been drilled, plastic anchor needs to be inserted into the holes, as shown in the picture 6.
7. Screws up the product on the wall with a screwdriver, as shown in the picture 7.
8. When all the screws have been tighten, the product has been installed and fixed on the wall, as shown in the picture 8.
9. Push cable connector from the leader cable to connect with the fixture, as shown in picture 9



rev 01/26

© 2026 Ace Illuminations. All rights reserved.

Specifications and content subject to change without notice. Protected by international copyright laws.
info@aceilluminations.com | 702.960.4249

cont. on 3